

Installation Instructions

1. Perform pre-alignment checks in a normal manner.
2. Install alignment equipment; record readings and determine amount of change needed.
3. Raise vehicle by frame and support in a safe manner.
4. Remove the OE cam bolt.
5. Install new cam bolt (pump with grease after installed if applicable).
6. Lower vehicle and adjust cam bolt. When all adjustments are made tighten all bolts to manufacture's specifications
7. Proceed with alignment and road test vehicle.