

Rear Wheel Brake Caliper Installation Instructions

These spacers are used when an alignment shim is installed and the caliper does not move with the rotor and binding between the rotor and caliper has occurred

1. Install rear full contact shim per instructions. Note: leave disc brake caliper off to install shim alignment caliper spacers
2. Install caliper loosely, noting where the alignment of the rotor and caliper meet
3. Use the stackable spacers between the caliper and caliper mounting bracket to best align the brake caliper and rotor
4. Torque caliper mounting bolts to manufacturer's specifications
5. Recheck the alignment of the rotor to the caliper, making sure it is centered and no binding has occurred
6. Reinstall wheel and any other bolts that were removed or loosened. Torque to manufacturer's specifications
7. Finish alignment and road test vehicle

